




element™ Setup Guide



! Make sure to keep the fan and vents clear of any obstructions.

For information about MIDI and Remote Trigger, please see the Eos Family Show Control User Guide.



Element supports up to 2 monitors using the following combinations:


Signal Type / Physical Port	Display Port	DVI	VGA
Display Port	Yes	Yes with Adapter	Yes with Active Adapter
DVI-I Port	No	Yes	Yes with Adapter
DVI-D Port	No	Yes	No

Multitouch monitors need to be Windows 7 or 8 Compatible.




USB ports are used to connect a keyboard, mouse, and/or USB flash drives. One additional port is located on Element's face panel.

5 pin XLR DMX Cables plug into the DMX ports to connect Element with dimmers, scrollers, moving lights, and other devices.



The phone remote jack is for plugging in a cordless phone for remote control of Element. Please see the Element User Manual for more information.



Corporate Headquarters ■ 3031 Pleasant View Road, P.O. Box 620979, Middleton, Wisconsin 53562-0979 USA ■ Tel +608 831 4116 ■ Fax +608 836 1736
 London, UK ■ Unit 26-28, Victoria Industrial Estate, Victoria Road, London W3 6UU, UK ■ Tel +44 (0)20 8896 1000 ■ Fax +44 (0)20 8896 2000
 Rome, IT ■ Via Pieve Torina, 48, 001569 Rome, Italy ■ Tel +39 (06) 32 111 683 ■ Fax +44 (0) 20 8752 8486
 Holzkirchen, DE ■ Ohmstrasse 3, 83607 Holzkirchen, Germany ■ Tel +49 (80 24) 47 00-0 ■ Fax +49 (80 24) 47 00-3 00
 Hong Kong ■ Rm 1801, 18/F, Tower 1 Phase 1, Enterprise Square, 9 Sheung Yuet Road, Kowloon Bay, Kowloon, Hong Kong ■ Tel +852 2799 1220 ■ Fax +852 2799 9325
 Service: (Americas) service@etcconnect.com ■ (UK) service@etc-europe.com ■ (DE) techserv-hoki@etcconnect.com ■ (Asia) service@etc-asia.com
 Web: www.etcconnect.com ■ Copyright © 2014 ETC. All Rights Reserved. ■ Product information and specifications subject to change.
 4330M2200 ■ RevC ■ 2014-04 ■ ETC intends this document to be provided in its entirety.