

ETC Setup Guide

SmartBar™/SmartModule Power Connection

Wiring Instructions

Please follow these notes for trouble-free power connections:

- Black wire is Phase 1 Hot
- Red wire is Phase 2 Hot
- Orange wire is Phase 3 Hot
- White wire is Neutral
- Green wire is Ground



WARNING: It is important to verify these connections as a mis-wired unit will not power up and must be returned to ETC for factory service. There may also be a charge associated with the repair of the product.

Please note that if installing a 3-phase Twist-Lock® connector, the three power landing locations are denoted as X, Y, and Z on the connector.

Neutral is marked as W and Ground is marked as G in the center pin.



WARNING: Do not confuse Z with N on the connector and accidentally reverse your neutral and power wires.

